

CLIPPER

Installation and Operation Manual

Product No. AY-CLIP



Contents

General Safety instructions	2
Safety precautions	2
Precautions for use	5
Precautions for use of synthetic leather	6
Position of warning label	6
About this product	6
Names of components	7
Accessories	7
Installation procedure	8
Read before use	12
Operating instructions	13
1 Guiding the customer into the chair	13
2 Adjusting the chair height	14
3 Headrest adjustment and mounting/removal	15
4 Reclining and raising the backrest	16
Daily maintenance procedure	17
Daily inspection procedure	17
Specifications	18
Standard period of use	19
Availability of maintenance parts	19
Consumables	19
Disposal of this product	19
Daily Inspection Guide	20

Thank you very much for purchasing a product from Takara Belmont.

Please read through and fully understand this Installation and Operation Manual to ensure proper use.

Failure to read this Installation and Operation Manual before use may result in an accident

This product is commercial equipment for use in barbershops and beauty salons. Do not use for any purpose other than hair and beauty treatments.

Keep this Installation and Operation Manual in a safe place for future reference.

Contact and inform us of the serial number to request a replacement copy of this Installation and Operation Manual if illegible due to smearing, tearing, etc., or loss.

November, 2016

1A0KDMA0

Second edition

General safety instructions

■ Read before use

Before use, read the “Safety precautions” and “Precautions for use” carefully to ensure proper use.

■ The following information

is intended for safe use of this product and to prevent injury and damage to you and others.

These instructions contain important safety information. Be sure to comply with them all.

We shall not be held responsible or liable to the user or any other person for any personal or property damage resulting from accidents that may occur owing to failure to comply with the “Safety precautions” or “Precautions for use.” Such physical or property damage shall be the responsibility and liability of those who failed to follow the safety instructions during use.

Read and understand the meanings of the following warning symbols before proceeding:

■ About the warning symbols

 WARNING	indicates information that, if ignored or applied incorrectly, may result in death or serious injury to the operator and others.
 CAUTION	indicates information that, if ignored or applied incorrectly, may result in minor or moderate injury and property damage.
NOTICE	indicates other useful information for ensuring safety.
 indicates a general caution, warning, or danger.	 indicates prohibition of disassembly, repair, or modification. <small>No disassembly</small>
 indicates a general prohibited action.	 indicates a general action required of the user.

Safety precautions (Be sure to observe them)


 WARNING	
<p>Do not move the chair with a person seated on it.</p>  Do not move the chair with a person seated on it. Failure to comply may cause the equipment to topple over, resulting in damage to it and an accidental fall.	<p>Do not sit on the backrest with it reclined.</p>  Do not sit on the backrest or apply excessive force thereon with it reclined. Failure to comply may result in damage or an accidental fall.
<p>Avoid use with plating peeled off.</p>  When the plating on any part is peeled off, immediately contact Takara Belmont or the nearest dealer for maintenance parts. Continued use without repair may result in injury.	<p>Stop use in case of a jam or if something feels wrong.</p>  In case of a jam or if something feels wrong, stop use immediately and contact us, or contact the dealer nearest you.
<p>Do not use the product outside its intended purpose.</p>  This product is designed to seat a person receiving a hair wash, haircut, and shaving. Use of the equipment for any unintended purpose may result in damage to the equipment or an accident.	<p>Do not recline or raise the backrest while performing service.</p>  Do not recline or raise the backrest while performing service. If the backrest is reclined especially during a haircut, injury may result from contact with the scissors.

Safety precautions (Be sure to observe them)



WARNING (Continued from previous page)

Comply with the following when adjusting the chair height:



Before adjusting the chair height, always ensure that no one is in the gap near the chair or the step. The chair has a considerable weight and may cause serious injury to a person caught in the gap.

Be careful when relocating the chair.



To relocate the chair, tilt the chair to one side, spread a mat underneath, and pull the mat with the chair on it according to the "Installation Procedure" (see page 11). If this is impossible, move the chair by holding its base. Never attempt to carry the chair by holding only its main body. Failure to comply may cause the chair base to be dislodged and fall off, resulting in serious injury. Also carefully avoid touching the bottom side of the seat or that of either armrest. Contact with the rough metal surface may result in cuts to the hand or fingers.

Be careful to use care to prevent contact of the customer or any other person with the reclining lever or the foot pedal.



Be careful during procedure to prevent contact of the customer or any other person with the reclining lever or the foot pedal. If accidentally unlocked, the backrest may spring back up or otherwise abruptly move, causing the chair to lose balance and topple over. Especially when its height is elevated, the chair may often become unstable and more prone to topple.

Comply with the following when using the step:



- Do not get up on the step with the chair in an elevated position.
- Do not apply a load of 30 kg or more to the edge of the step.
- Use care when getting up on and down from the step.

Failure to comply with the above may cause the chair to topple over or be damaged, resulting in injury. If the customer gets on the step, be sure to hold the backrest of the chair with both hands to prevent the chair from toppling over.

Recline or raise the customer slowly with their head supported by hand.



Recline or raise the customer slowly. Failure to comply may cause head injury to the customer due to collision with the shampoo bowl. Lying on or rising up from the backrest too fast may cause the chair to lose balance and topple over. Especially when its height is elevated, the chair may often become unstable and more prone to topple over. Use sufficient care.

Retract the headrest carefully.



Retract the headrest carefully not to get the hand pinched. Failure to comply may result in injury.

Be careful with the chair base when sit on and get up from the chair




Sit on and get up from the chair carefully not to get a foot caught by the chair base. Getting a foot caught may result in injury from a fall.

Bring the chair to its lowest position for the customer to sit on and get up from it.



Bring the chair to its lowest position for the customer to sit on and get up from it. Failure to comply may cause the chair to topple over, resulting in injury.

Never attempt unauthorized disassembly, repair, or modification.



No one other than our repair technicians shall attempt disassembly or repair. Failure to comply may result in an accident or malfunction.

Allow only one person to sit on the seat at a time.



Allow only one person to sit on the seat at a time. Do not allow anyone weighing 135 kg or more to sit on the seat. Failure to comply may cause malfunction or damage to the equipment, resulting in injury.

Ensure that there are no hands or fingers in any gap in the equipment before operating the chair.



Before operating the chair, carefully ensure that there are no customer hands or fingers in any gap. Failure to comply may result in serious injury to the hand(s) or finger(s) pinched.

Do not sit on either armrest.



Do not sit on either armrest. Failure to comply may cause the chair to topple over, resulting in injury.

Do not stand on top of the chair.



Do not stand on top of the chair. Failure to comply may cause damage to the chair, resulting in injury.

Safety precautions (Be sure to observe them)



CAUTION

Do not place any non-human object on the seat.



Do not place any non-human object on the seat. Failure to comply may result in deformed, torn, or corroded leather.

Install on a stable surface.



Install the chair on a flat, hard floor. Failure to comply may cause the chair to topple over.

Protect the equipment against impact.



Protect the equipment against impact. Failure to comply may cause damage to the equipment, resulting in injury.

Do not lean on the chair.



Do not lean on the chair inadvertently. Failure to comply may cause the chair to turn and topple over, resulting in injury.

Do not pull on the cord of a dryer, etc., caught by the chair.



Do not pull on the cord of a dryer, etc., caught by the bottom, armrest, or backrest of the chair. Pulling on the cord or operating the chair with the cord caught may cause damage to the chair, the dryer, etc., resulting in electric shock or injury.

Do not stand on the step.



Do not stand on the step. Failure to comply may cause the adjuster of the step to deform or the chair to topple over. Additionally, the adjuster or the step may hit on the floor and cause damage to the floor.

Look around before turning the chair around.



Before turning the chair around, always ensure that there is no person or object around it (especially around the step). Collision with a person or object may cause damage to the equipment and objects or result in personal injury.

Do not allow the customer to adjust the backrest angle.



Do not allow the customer to adjust the backrest angle. Adjustment during procedure or operation using more force than necessary may result in injury or damage to the equipment.

Precautions for use



CAUTION

<p>Do not wipe with chemicals or apply heat.</p>  <p>Failure to comply may result in deterioration or discoloration. In case of chemical spillage on the leather-upholstered part or covers, wipe clean immediately.</p>	<p>Always wipe and dry the floor if wet.</p>  <p>Wipe and dry the floor immediately if it is wet after shampooing. Failure to comply may cause deterioration to the floor surface or failure to the chair base.</p>
<p>Do not operate using more force than necessary.</p>  <p>Do not apply excessive force to the equipment or use more force than necessary for its operation. Failure to comply may result in damage to the equipment.</p>	<p>Keep pointy objects away from the leather-upholstered part.</p>  <p>Contact with any pointy object may result in torn, scratched, or otherwise damaged leather.</p>
<p>Do not use in contact with a processor.</p>  <p>When using the chair in combination with a processor, carefully prevent contact between them. Failure to comply may result in discolored or deteriorated vinyl leather.</p>	<p>Do not apply excessive force to the edge of the backrest or that of either armrest.</p>  <p>Do not apply excessive force to the edge of the backrest or that of either armrest to turn or move the chair. Failure to comply may cause deformation or damage to the equipment.</p>
<p>Protect from exposure to direct sunlight or heat radiation from heating appliances.</p>  <p>Protect from exposure to direct sunlight or heat radiation from a stove and any other heating device. Failure to comply may result in discolored, deteriorated, deformed, or degraded leather. Avoid use on a heating appliance such as an electric carpet. Failure to comply may result in fire.</p>	<p>Do not use outdoors.</p>  <p>This product is for indoor use only. Do not install outdoors or in vehicles. Always use inside a barbershop or a beauty salon. Failure to comply may cause malfunction or damage to the equipment.</p>
<p>Do not forcefully lift up the main body or backrest of the chair.</p>  <p>Failure to comply may cause malfunction or damage to the equipment.</p>	<p>Always wipe and dry the equipment after use.</p>  <p>Failure to remove moisture after use may cause malfunction to the equipment or result in unremovable smudges.</p>
<p>Do not leave leather or vinyl products, denims, magazines, etc., on the leather-upholstered part.</p>  <p>Prevent close contact of the leather-upholstered part (backrest, seat, and armrests) with other leather products (handbags, etc.), vinyl products, copy paper sheets (print side), or print publications (books and magazines). Failure to comply may cause the dye or ink to migrate and adhere fast. Use sufficient care with handbags, denims and other clothes, and magazines among other things (potential color migration from customers' leather products, synthetic leather clothes, etc.).</p>	<p>In case of chemical spillage, wipe clean immediately.</p>  <p>In case of spillage of hair dye or any other chemical, wipe clean immediately. Failure to comply may result in discoloration, deterioration, or deformation. In case of chemical spillage on the floor, wipe clean immediately. Note that hair dyes have a very strong coloring power. Hence, wiping immediately after spillage may fail in complete removal and leave tint behind.</p>

- To ensure safe use of the product, perform inspection according to the “Daily Inspection Guide” on page 20 of this operating manual.

Precautions for use of synthetic leather


●Dye migration from clothes

The synthetic leather used in this product may be susceptible to dye migration due to contact with clothes or belts. In case of dye migration, wipe clean immediately to prevent penetration due to plasticizer. Wipe clean using a soft cloth soaked with a 10-percent solution of neutral detergent diluted with water. Then, wipe with a dry cloth.

●Precautions against deterioration and dye migration due to contact

- Contact with other resin parts or coated parts, solvent, adhesive tape or the like may cause reduced gloss, cracks, deformation, or peeling of the surface.
- Contact with newspapers or print publications may result in dye migration.
- Contact with T-shirt printed fabrics, etc., denim clothes, etc., may result in dye migration to the leather.
- Contact with benzene, nail-polish remover, alcohol, or the like, may result in discoloration, surface dissolution, plasticizer elution, reduced gloss, hardening or softening, or peeling.
- Exposure to a bleaching agent or contact with a bleached sheet may result in reduced gloss or discoloration.
- Close proximity to extreme heat sources such as an iron or a heater may cause deterioration or discoloration.
- Use a curtain or the like to prevent exposure to direct sunlight. Failure to comply may result in surface deterioration, shrinkage, discoloration, or fading.
- Do not leave heavy load on. Failure to comply may result in permanent marks or wrinkles.

Position of warning label



About this product

This product is a barbershop/beauty salon chair intended for haircutting, coloring, or use in combination with a processor for performing or coloring. To ensure safe use, carefully read in advance this operating manual along with the operating manual of the perm machine to be used in combination.

●Wrinkles in the leather



This product contains some parts wrinkled for aesthetic purposes. Additionally, soft cushioning is used to give volume and tension to the chair. These wrinkles may be stretched over time or depending on the conditions of use.



CAUTION

In the case of combined use with a processor, use care to prevent contact between the chair and the processor. Failure to comply may result in discolored or deteriorated leather.

Names of components



Accessories

Check and ensure that there are no missing accessories.


Installation and Operation Manual

Headrest

Installation procedure

■ About the chair installation space

Install the chair with space sufficient for rotation.
The range of rotation for the chair is as shown to the right.



CAUTION

● Install on a stable surface.

Install the chair on a flat, hard floor. Failure to comply may cause the chair to topple over.


● Look around before turning the chair around.

Before turning the chair around, be sure to ensure that there is no person or object around it (especially around the step). Collision with a person or an object may result in injury or damage to the equipment or the object.


● Protect from exposure to direct sunlight or heat radiation from heating appliances.

Protect from exposure to direct sunlight or heat radiation from a stove and any other heating device. Failure to comply may result in discolored, deteriorated, deformed, or degraded leather. Avoid use on a heating appliance such as an electric carpet. Failure to comply may result in fire.

- (1) Using the L-shaped wrench (size 6), slightly loosen Screws A fixing the step to the gooseneck.
(Screw A is found on each of the left and right sides.)




- (2) Fold the step forward to fix it to the gooseneck using the screws and Screws A.
(Fasten each of the four screws on the left and right sides similarly.)



Installation Procedure


■ Installing the adjuster

Screw the step adjuster into the step, adjust the step to an appropriate height, and tighten and fix the nut fitted to the adjuster to the step using the WAF-17 spanner.




■ Inserting the headrest

Press down the headrest retraction button to insert the headrest in place.
Be careful with the orientation of the headrest (front-to-back orientation).



■ Relocation of the chair

Tilt the chair to one side to spread a mat underneath to prevent damage to the floor.
Holding the chair to prevent it from falling, move the chair by pulling the mat spread beneath it without the base dragging on the floor.



 WARNING	<ul style="list-style-type: none"> ● Do not move the chair with a person seated on it. Failure to comply may cause the equipment to topple over, resulting in damage to it or an accidental fall. ● When required to lift up and move the chair, be sure to lock the chair base and carry the chair by two persons holding the base. Never attempt to carry the chair by holding only its main body. Failure to comply may cause the bottom section (chair base) to be dislodged and fall off, resulting in serious injury. <p>Also carefully avoid touching the bottom side of the seat or that of either armrest. Contact with the rough metal surface may result in cuts to the hand or fingers.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Wrong method</p> </div> <div style="text-align: center;">  <p>Correct method</p> </div> </div>
---	--

 CAUTION	<ul style="list-style-type: none"> ● Never attempt to drag and move the chair without a mat spread underneath it. Failure to comply may cause damage to the floor or a malfunction or damage to the equipment.
---	---

Read before Use

This product comes complete with a step for the feet. The following instructions contain important information on the step to ensure safe use of the product. Be sure to comply with these instructions.



WARNING

- **Comply with the following when adjusting the chair height:**

Before adjusting the chair height, always ensure that no one is in the gap near the chair or the step.

The chair has a considerable weight and may cause serious injury to a person caught in the gap.



- **Bring the chair to its lowest position for the customer to sit on and get up from it.**

Bring the chair to its lowest position for the customer to sit on and get up from it.

Failure to comply may cause the chair to topple over, resulting in injury.



- **Whenever guiding the customer to the step to sit on and get up from the chair, hold the backrest of the chair with both hands to prevent the chair from turning over or becoming otherwise unstable.**



CAUTION

- **Look around before turning the chair around.**

Before turning the chair around, always ensure that there is no person around it (especially around the step). Collision with a person may result in personal injury.



- **Do not turn the chair around with the adjuster in contact with the floor.**

This product comes complete with an adjuster beneath the step as a precaution against accidents.

Do not turn the chair around with the customer sitting on the edge of the seat. Failure to comply may disable the rotation of the chair with the adjuster stuck on the floor, causing malfunction to the chair or damage to the floor surface. Whenever guiding a customer into the chair, ensure that the customer sits back in the chair.



Operating instructions

1 Guiding the customer into the chair


Turn the chair to a position most convenient for the customer.

Guide the customer to the chair.

Bring the chair to its lowest position to help the customer to get seated on it.

1. Step lightly on the foot pedal to unlock the chair.


The chair is then ready to rotate.



2. Rotate the chair.


When turning the chair, hold the backrest or one of the armrests.

The chair is capable of 360 degrees of free rotation.



3. Lock the chair in the work position.

With the chair held in the work position, kick up the foot pedal to lock the chair so that it does not move.



WARNING

- **Bring the chair to its lowest position for the customer to sit on and get up from it.** Bring the chair to its lowest position and lock it for the customer to sit on and get up from it. Sitting on or getting up from it in any other position will compromise the effect of the adjuster and may result in personal injury due to a fall.



CAUTION



- **Before turning the chair around, always ensure that there is no person around it.**
- **When not required to turn the chair, be sure to engage its lock.**

Operating instructions

2 Adjusting the chair height

1. Adjusting the chair height up



Step on the foot pedal lightly in succession to adjust the chair height up slowly.



⇒ Carefully avoid stepping too hard. Failure to comply will result in the lowering of the chair height.

2. Adjusting the chair height down

To adjust the chair height down, step hard on the foot pedal to the lowest position. The chair height continues to decrease as long as the foot pedal is stepped on. (Engage the lock after the operation.)



WARNING

- Before a chair height adjustment operation, always ensure that there is no person in the gap near the chair or the step. The chair has a considerable weight and may cause serious injury to a person caught in the gap.
- During chair height adjustment, the rotation prevention lock is disengaged. After the chair height adjustment, kick up the foot pedal to engage the rotation prevention lock back on and ensure safety.



CAUTION


Do not operate the chair with a person on the step. Failure to comply will result in abnormal noise and other problems.

Operating instructions

3 Headrest adjustment and mounting/removal

1. Press down the headrest retraction button to insert the headrest.

Without pressing down the headrest retraction button, the headrest cannot be inserted in place.




2. Adjust the headrest to the customer's head height.

The headrest height can be adjusted in six steps up and down.

The headrest can be pulled up without pressing down on the headrest retraction button.

If the headrest is pulled up too much, press down on the headrest retraction button to move the headrest to its lowest position first and then up to the correct height.

The positions at which a clicking sound is heard as the headrest is pulled up are the fixation positions.



WARNING

When retracting the headrest, use care not to pinch the hand. Insufficient care may result in injury.



CAUTION

- Never use the headrest in any position other than the six adjustment positions. Failure to comply may result in serious injury if the headrest moves during procedure such as shaving.
- Remove the headrest before shampooing the customer with their head leaning back over the bowl. Reclining the backrest with the headrest inserted in place may result in damage to the chair and the shampooing equipment or injury to the customer.

Operating instructions

4 Reclining and raising the backrest

The backrest can be unlocked by operating the reclining lever.

The backrest can be moved only while the reclining lever is pulled down in the direction indicated by the arrow.

1. When reclining the backrest


Pull the reclining lever down in the direction indicated by the arrow and recline the backrest slowly with a hand on it.

2. When raising the backrest

Pull the reclining lever in the direction indicated by the arrow and raise the backrest slowly with a hand on it.

The reclining lever may be on the right or left side depending on the destination of delivery.

(A right-side lever type is shown here.)



WARNING

- Before a chair height adjustment operation or a backrest reclining or raising operation, always ensure that there are no hands or fingers in any gap in the chair. Failure to comply may result in serious injury to the hand(s) or finger(s) pinched.
- Do not recline or raise the backrest while performing services. If the backrest is reclined especially during a haircut, injury may result from contact with the scissors.
- Recline or raise the customer slowly. Failure to comply may cause head injury to the customer due to collision with the shampoo bowl. Lying on or rising up from the backrest too fast may cause the chair to lose balance and topple over. Especially when its height is elevated, the chair may often become unstable and more prone to topple over. Use sufficient care.
- Use care while performing services to prevent contact of the customer or any other person with the reclining lever or the foot pedal. If accidentally unlocked, the backrest may spring back up or otherwise abruptly move, causing the chair to lose balance and topple over. Especially when its height is elevated, the chair may often become unstable and more prone to topple over. Use sufficient care.




CAUTION

- Before a backrest reclining or raising operation, always ensure that there is no person or object around it. Collision with a person or object may cause damage to the equipment or result in personal injury.
- When the reclining lever is moved slightly, the backrest will be ready for operation. Do not use more force than necessary for operation or attempt to reverse the operating direction. Failure to comply may result in malfunction.
- Do not allow the customer to adjust the backrest angle. Adjustment while performing services or operation using more force than necessary may result in injury or damage to the equipment.
- To prevent the backrest from moving abruptly, be sure to hold it with a hand on it.

This product is commercial equipment dedicated for procedures or services at barbershops and beauty salons and shall be operated only by experienced barbers or hairdressers or personnel under their supervision.


Daily Maintenance Procedure

- After a day's work, perform daily maintenance on the chair. Failure to clean the chair may result in mold growth.

 CAUTION	<p>Never use thinner, alcohol, gasoline, kerosene, or any other volatile chemical, abrasive-containing wax or sponge, organic solvent-containing cleaners, acid, alkali, or chloride-based cleaners, or cleaning tools, such as a scrub brush. Their use will result in scratches, discoloration, or other damage.</p>	
---	--	--

Synthetic leather-upholstered part

- Wipe with a dry and/or water-dampened cloth as necessary.
- When heavily soiled, use a soft cloth soaked with a 10-percent solution of neutral detergent diluted with water. Then, wipe with a water-dampened cloth and then remove moisture sufficiently.
- In case of dye migration from clothes or belts, wipe clean immediately in the same way as when heavily soiled to prevent penetration due to plasticizer. Do not wait until the end of the day.



 CAUTION	<ul style="list-style-type: none"> ● Avoid rapid drying using a dryer or the like. ● Clean the equipment carefully to prevent contact with any cleaning tool. Failure to comply may result in scratches or damage to the equipment. ● Clean the equipment carefully so that grease leaking from the chair base will not stain clothes. ● After wiping with a water-dampened cloth, remove moisture sufficiently. Any moisture left behind may promote hydrolysis. Do not use solvents or bleaching agents. ● Do not use solvent- or abrasive-containing leather cleaners. Failure to comply may cause deterioration to the surface, resulting in a change in texture or gloss. Before using a leather cleaner, try it on a visually unobtrusive spot first to ensure that no discoloration occurs. ● Do not use brushes, scrub brushes, or the like for maintenance. Their use may result in scratches or unremovable smudges.
---	--

Metal parts

- Wipe lightly with a dry, soft cloth.
- In case of water or chemical spillage, wipe clean immediately to prevent rusting. Do not wait until the end of the day.

Always keep dry!

 CAUTION	<p>The chair has fixation screws, metal parts, and the like on its bottom. Carefully avoid touching them with the hand during maintenance. Failure to comply may result in injury.</p>
---	--

Daily inspection procedure



- Perform daily inspection according to the "Daily Inspection Guide" on page 20 of this operating manual to ensure safe and long use of the product.



Be sure to perform daily inspection according to the "Daily Inspection Guide." Continued use without daily inspection may result in malfunction or accidents.

Specifications

Product number	AY-CLIP	
Weight	Main body of the chair	44 kg (97 lb)
Reclining angle	30° as reclined to 75° as raised	
Load capacity	1,350 N (135 kgf, 298 lb)	
Upholstery material	PVC leather	



Chair with SLIM-R BASE (AN-B5110)

About the standard period of use

- The standard period of use of this product is seven years.
- The standard period of use is the standard period for safe use of a product used under the product-specific normal conditions and subjected to proper maintenance and inspection (including parts replacement). This is not the warranty period. The standard period may vary depending on the customer's usage environment and frequency. For maintenance after the end of the standard period of use, contact us or the dealer nearest to you.

Availability of maintenance parts

- We keep an inventory of product maintenance parts, including consumables and periodic replacement parts, for seven years.
Note: Maintenance parts are those necessary to repair the product and return it to its original condition and function or maintain its function.

Consumables

- The following parts are consumables and will show wear, deterioration, change in appearance, or damage over use. Be aware that their repair or replacement is outside the scope of warranty and available only for charge.
(*The degree and timing of wear, deterioration, or damage may vary depending on the customer's usage environment and conditions.)
In the event of extreme wear, deterioration, or damage, inspection or parts replacement will be necessary. Contact us or the dealer nearest you immediately.

Consumables (the following parts) are outside the scope of warranty and available only for charge.

- There are no consumable parts designated for this model.

As for the following exterior components, their exterior scratches, smudges, deterioration, discoloration, and the like shall fall outside the scope of warranty:

- Upholstered part (leather, cushioning, threads, etc.)
- Step
- Adjuster
- Reclining lever

Disposal of this product

This product or replaced parts shall be properly disposed of in accordance with the laws and regulations applicable at the time of their disposal.

