





Assembly Procedures for Stand-Type Spa Mist II Mist Processor ①

Parts Required for Assembly

(※ For the assembly work, a No. 2 Phillips-head screwdriver is required.)



After unpacking the carton, check that the contents shown below are included.

• Contents of Stand for AY-160S Spa Mist II Processor



The following parts come with the main Spa Mist II Processor unit.


• Accessories for AK-160S Spa Mist II Processor




Assembly Procedures for Stand-Type Spa Mist II Mist Processor ②

Assembly Procedures


- ① Take the main unit of the packing case, and place it on the packing case that is laid down as shown below.
※Pay attention not to drop the unit from the case.



- ② Mount the column support for the stand as shown below, and secure it firmly with the furnished screws using the L-shaped wrench. (4 points)




- ③ Mount the stand base on the column support as shown below, and secure it firmly with the furnished screws using the L-shaped wrench. (4 points)



⚠ CAUTION
Be sure to tighten the screws while holding the stand base.
(※The weight of the stand base may tilt the product, resulting in breakage of the machine or physical injury.)

- ④ Secure the power cord, to the main unit using the furnished inlet stopper and screw.



⚠ CAUTION
Be sure to insert the power cord all the way to the end.
(※If the insertion of the power cord is insufficient, there is a possibility of heat generation, fire, etc.)

※Perform the following inspections at the end of the above-stated procedures.
•Check that all screws have been tightened. Be sure to check the screws at all nine points.
•Check that the screws are fully tightened. Check for any loose screws at all nine points.