


# CARE DRY G

## QUICK OPERATION GUIDE







For details and safety information  
see the operating instructions.

<https://manual.tb-global.net/>






## 1 Time setting buttons



\* Maximum set time: 60 minutes

## 2 Temperature level setting buttons/ lamps




[Display Colour]

RED  
ORANGE  
YELLOW  
GREEN


\*3° each from top to bottom  
RED = 46°, GREEN = 34°

## 3 Mode selection buttons




Dry mode selection buttons

S: For short hair  
M: For the sides  
L: For long hair












Heat mode selection buttons

540°: For short to medium hair  
360°: From the top of the head to the shoulder  
120°: For medium to long hair




## 4 Display panel


Error indication

	Incorrect head position error
	
	Heater error
	Heater control error
	Fan error
	
	Unit position error
	Infrared thermal sensor error
	Reminder of mesh cleaning


- 1 Adjust the height using both hands



- 2 Attach the setting gauge



- 3 Setting the Care Dry G in the correct position




- 4 Alarm rings when the head position is misaligned

Misaligned position alarm! 




### 3 Operation procedures


- 1 Set the Care Dry G in the correct position.



- 2 Plug in and turn on the power switch.



- 3 Press the key for the desired mode.



- 4 Press the START/STOP button




## 5 During Operation

<Heater unit movement patterns>


Swings 180°

In S or M dry mode or in cool mode




Swings 120°

In L dry mode and 120° heat mode




Swings 540°

In 540° heat mode




Rotates 360°

In 360° heat mode



## 8 Switch off and unplug when not in use





TAKARA BELMONT CORPORATION

2-1-1, Higashishinsaibashi, Chuo-ku, Osaka, 542-0083, Japan

TEL : 81-6-6213-5945

FAX : 81-6-6212-3680

