

YUME ESPOIR QUICK OPERATION GUIDE



For details and safety information see the operating instructions.

https://manual.tb-global.net/






Seat lifting switch Press one second or longer for preset position

Press one second or less for manual mode

Seat lowering switch Press one second or longer for initial position


Press one second or less for manual mode





How to set the preset position

- 1) Set the chair to the desired position
- 2) Turn off the power switch
- 3) While depressing the Preset Button, turn on the power switch
- 4) Keep depressing the Preset Button until the buzzer sounds, then release


Shampoo Basin









To adjust the temperature over 40 degrees, turn the knob while pressing the Stop Button.









<YUME shower head>



<Side shower head>



<Dual Function Showerhead [OPTION]>







<Shower Mode>






Shower head holder






Back wash basin (YUME basin)


1 Attach the Neck Cushion and Head Pillow.



2 Attach both sides of the Neck Cushion with the snap button.




3 Attach the Head Pillow as shown below.




Side wash basin


1 Attach the Neck Cushion.




1 Turn on the power.




2 Press the seat lowering switch for 1 second or longer to bring the chair to its initial position.




Instruct the customer to sit from the side, then face front.



4 Press the seat lifting switch for 1 second or longer to bring the chair to its preset position.




5 Adjust the chair height.





Confirm that there are no objects/ people between the seat and the floor when operating the chair.



<Shampooing Style>


Back wash shampoo (seated)




Side wash shampoo (standing)




6 After the shampooing, return the chair to its initial position.



Wipe off the remaining water after use.



8 Clean the consumable parts.





TAKARA BELMONT CORPORATION

2-1-1, Higashishinsaibashi,Chuo-ku,Osaka, 542-0083, Japan

TEL: 81-6-6213-5945 FAX: 81-6-6212-3680